

MODKIT 38

PHOENIX KITS



SHARP 59DS03H66DS-05H CA10 Chassis

Symptoms.

Set Dead Fuse blown Q701 "short circuit"

Fit Q601,D712,F701,Q701 and check all other associated components resolder all capacitors around this transistor plus resolder scan coil connections, If Red LED is a light replace C806 and R713 as well as above.

Stuck in Stand -by

Check Q702,Q601, C613, R704,R705,R713,R714

No Picture

Check R613,C613,C619.

Kit contains:-

1	BUH515	Q601
1	2SK2605	Q701
1	15V Zener	D712
1	3.15A Fuse	F701
1	BC338=BC337	Q702
1	.68 250V	C613
1	2.2mFd 400V	C619
1	4700Pf 100v	C806
1	2K2 2W	R613
2	68K .6W	R704,R705
2	560K .6W	R713,R714

Since the end result depends on your own skill and fault finding ability, the supplier will accept no responsibility for loss, damage or injury caused by your use of this kit. This is expressly sold on the above understanding and that the decision to use the kit is the responsibility of the kit user.

See an up to date listing of all our kits on our Web site :-
phoenixkits.co.uk